



STEDMAN

PureConnect™

PK-2 CLEANER KIT INSTRUCTIONS



Cleaning 1/4" Female Connector

1. Thread flat end of 1/4" felt tip into the 1/4" threaded hole of handle.
2. Apply a small amount of cleaner fluid to the tapered end and 1" from tip.
3. Insert felt tip into connector and rotate handle clockwise 1 full turn (2 twists).
4. Pull out from connector and inspect tip. Replace tip when gray residue can be seen on tip.



Cleaning 1/4" Male Connector

1. Apply two drops of cleaner fluid to the cotton pad. One in the center and one between the center and the outer edge.
2. Rotate connector in pad insuring cleaner is in contact with plug sleeve and tip.
3. Replace pad when dirty.

Cleaning XLR Female Connector

1. Thread flat end of 1/10" felt tip into the 1/10" threaded hole of handle.
2. Apply a small amount of cleaner fluid near end of the tip.
3. Insert tip into each female XLR terminal and rotate handle clockwise 1 full turn (2 twists) and remove.
4. Inspect tip and replace if gray residue can be seen on tip.



Cleaning XLR Male Connector

1. Thread tapered end of 1/4" felt tip into the 1/4" threaded hole of handle.
2. Apply a small amount of cleaner fluid into the small hole at flat end of felt tip.
3. Press felt tip onto each male XLR pin and rotate handle clockwise 1 full turn (2 twists) and remove.



For more detailed instructions visit www.stedmanusa.com

STEDMAN

® 9625 East D Ave
Richland MI 49083
Phone 888-629-5960



**NO
VOC's**

